

















































































Key sequence summary

HP-25E Quick Guide







Key sequence	Mode	Description
 	RUN	Enter stopwatch mode
 	RUN	Enter Hexadecimal entry mode
   - 	RUN	Store register set in Storage Memory 0 to 9
   - 	RUN	Recall register set from Storage Memory 0 to 9
    	RUN	Recall constant 0-99 from Constant Collection
    	RUN	Store constant 20-99 to Constant Collection
 	RUN	Show mantissa/Print X (HP-25E Ir)
 	RUN	Paper Advance (HP-25E Ir)
 	RUN	Show registers 0 to 7
 	RUN	Show statistical registers 3 to 7
 	PRGM	Insert program step
 	PRGM	Delete program step
 	PRGM	Show program steps/Print program (HP-25E Ir)
 	RUN	Single Step Debug
 	RUN	Undo restore stack registers
 	PRGM	Undo restore program step
   	PRGM	Goto program step 00 to 49
 	PRGM	Switch to RUN mode
 	RUN	Switch to PRGM mode
   	PRGM	Load program 00 to 99 from Program Library
    	PRGM	Store program 55 to 99 to Program Library
   - 	RUN/ PRGM	Enter function 0-9 (see function table)

Repeat keys














Key	Description
	Show stack
	Show XY registers
	Show program steps forward in PRGM mode
	Show program steps backward in PRGM mode

Function	Description
 	Enter Function Menu
	Show firmware revision and serial number
	Toggle flags
	Show calculator logo
	Show ROM code
	Show ROM checksum
	Show program number and checksum
	Show available Memory
	Show operating time
	Show Flash write cycles
	LED Test
	Enter welcome message

Power up keys

Key	Description
	Show firmware revision and serial number
 - 	Toggle Flags 0 to 9
	Toggle between Original mode and Extended mode
	Toggle between External ROM and Internal ROM firmware
	Flash internal ROM from external ROM when in RUN mode

Stopwatch keys

Key	Description
 	Enter and leave stopwatch mode
	Start and stop stopwatch timer A or B
	Start and stop stopwatch timers A and B simultaneously
	Reset stopwatch timer A or B
	Toggle between stopwatch timer A and B
	Game watch toggle between player A player B
	Start and stop calibration
  - 	Store Lap Times 0 - 7, Recall with   - 